





# SPARE PARTS LIST

CHAIN SAWS

362, 2013-12

**P** 362  
ACCESSORIES


## ACCESSORIES

362, 2013-12



| Ref | Part no.     | Description        | Remark | Qty | Kit |
|-----|--------------|--------------------|--------|-----|-----|
| 1   | 503 55 85-01 | TOOL               |        | 1   |     |
| 2   | 501 69 17-01 | COMBINATION WRENCH |        | 1   | 1   |
| 3   | 503 55 86-02 | SPANNER            | NV5    | 1   | 1   |
| 4   | 503 55 86-01 | SPANNER            | NV4    | 1   | 1   |
| 5   | 503 62 12-01 | GREASE             |        | 1   | 1   |
| 6   | 501 91 14-01 | GREASE GUN         |        | 1   | 1   |
| 7   | 503 96 90-08 | KIT                | WINTER | 1   |     |
| 8   | 503 21 27-16 | SCREW CRPANT       |        | 1   | 7   |

**N** 362  
CARBURETOR

# Walbro HD-6B




| Ref | Part no.     | Description         | Remark             | Qty | Kit   |
|-----|--------------|---------------------|--------------------|-----|-------|
| 1   | 503 28 18-04 | CARBURETTOR         |                    | 1   |       |
| 2   | 501 46 69-01 | SCREW               |                    | 1   |       |
| 3   | 503 79 98-01 | COVER               |                    | 1   |       |
| 4   | 501 66 69-01 | GASKET              |                    | 1   | 1, 44 |
| 5   | 502 25 47-01 | DIAPHRAGM PUMP      |                    | 1   | 1, 44 |
| 6   | 501 66 61-01 | SCREEN-INLET        |                    | 1   |       |
| 7   | 503 85 59-01 | FITTING             |                    | 1   |       |
| 8   | 503 80 14-01 | FITTING             |                    | 1   |       |
| 9   | 503 85 58-01 | VALVE               |                    | 1   |       |
| 10  | 537 01 91-01 | SHAFT ASSY          |                    | 1   |       |
| 11  | 537 01 89-01 | LEVER               |                    | 1   | 1, 10 |
| 12  | 501 46 87-01 | SCREW               |                    | 1   |       |
| 13  | 537 01 90-01 | SPRING              |                    | 1   |       |
| 14  | 501 46 85-01 | BALL-CHOKE FRICTION |                    | 1   |       |
| 15  | 501 46 84-01 | SPRING              |                    | 1   |       |
| 16  | 501 46 87-01 | SCREW               |                    | 1   |       |
| 17  | 503 79 96-01 | LEVER               |                    | 1   |       |
| 18  | 503 80 15-01 | WASHER              |                    | 1   |       |
| 19  | 503 80 00-01 | VALVE               |                    | 1   |       |
| 20  | 503 80 09-01 | SPRING              |                    | 1   |       |
| 21  | 530 03 50-15 | SCREW               |                    | 1   |       |
| 22  | 503 79 99-01 | SHAFT               |                    | 1   |       |
| 23  | 501 66 78-01 | SPRING              |                    | 1   |       |
| 24  | 503 80 08-01 | SCREW               |                    | 1   |       |
| 25  | 501 66 77-01 | SPRING              |                    | 1   |       |
| 26  | 503 80 11-01 | NEEDLE              |                    | 1   |       |
| 28  | 501 66 77-01 | SPRING              |                    | 1   |       |
| 29  | 504 02 72-13 | NEEDLE-IDLE SPEED   |                    | 1   |       |
| 32  | 503 57 42-01 | PLUG-WELCH          |                    | 1   |       |
| 33  | 503 80 04-01 | NOZZLE              |                    | 1   |       |
| 34  | 503 68 82-01 | JET                 |                    | 1   |       |
| 35  | 503 56 24-01 | SPRING              |                    | 1   |       |
| 36  | 503 56 34-01 | VALVE INLET NEEDLE  |                    | 1   |       |
| 37  | 501 66 83-01 | LEVER-METERING      |                    | 1   |       |
| 38  | 505 52 01-25 | PIN-METERING LEVER  |                    | 1   |       |
| 39  | 505 31 67-17 | SCREW               |                    | 1   |       |
| 40  | 504 13 09-05 | GASKET              |                    | 1   | 1, 44 |
| 41  | 503 80 07-01 | DIAPHRAGM           |                    | 1   | 1, 44 |
| 42  | 537 07 76-01 | COVER               |                    | 1   |       |
| 43  | 503 10 87-01 | SCREW               |                    | 4   |       |
| 44  | 503 64 78-01 | REPAIR KIT          | B = Set of gaskets | 1   |       |

**G** 362  
CARBURETOR & AIR FILTER

## CARBURETOR &amp; AIR FILTER

362, 2013-12


| Ref | Part no.     | Description     | Remark       | Qty | Kit |
|-----|--------------|-----------------|--------------|-----|-----|
| 1   | 575 26 91-01 | AIR FILTER ASSY | 80μ          | 1   |     |
| 1   | 575 26 91-02 | AIR FILTER ASSY | 44μ          | 1   |     |
| 1   | 575 26 91-03 | AIR FILTER ASSY | Felt         | 1   |     |
| 2   | 503 73 54-01 | CLAMP           |              | 1   |     |
| 7   | 725 53 05-55 | SCREW IHSCM     |              | 1   |     |
| 8   | 503 70 11-01 | TUBE            |              | 2   |     |
| 9   | 503 62 75-01 | FILTER HOLDER   |              | 1   |     |
| 10  | 503 68 41-01 | LEVER           |              | 1   |     |
| 11  | 503 66 53-01 | GUIDE BUSHING   |              | 1   |     |
| 12  | 503 28 18-04 | CARBURETTOR     | Walbro HD-6B | 1   |     |
| 13  | 503 40 06-06 | IMPULSE HOSE    |              | 1   |     |
| 14  | 503 43 18-01 | SUPPORT SLEEVE  |              | 1   |     |
| 15  | 503 71 27-01 | FLANGE          |              | 1   |     |
| 16  | 503 22 65-03 | SQUARE NUT      |              | 2   | 15  |
| 17  | 503 96 45-01 | INLET PIPE      |              | 1   |     |
| 18  | 505 28 33-01 | HOSE CLAMP      |              | 1   |     |

**A** 362  
CHAIN BRAKE & CLUTCH COVER

## CHAIN BRAKE &amp; CLUTCH COVER

362, 2013-12


| Ref | Part no.     | Description        | Remark | Qty | Kit    |
|-----|--------------|--------------------|--------|-----|--------|
| 1   | 503 20 02-12 | SCREW IHSCFM       |        | 4   |        |
| 2   | 503 75 11-03 | HUB CAP            |        | 1   |        |
| 3   | 503 21 28-10 | SCREW CCRPANT      |        | 1   |        |
| 4   | 501 87 53-03 | KNEE JOINT         |        | 1   |        |
| 5   | 503 20 26-02 | SCREW IHSCM        |        | 1   |        |
| 6   | 503 76 49-03 | HAND GUARD         |        | 1   |        |
| 7   | 503 43 65-01 | POSITION SPRING    |        | 1   |        |
| 8   | 503 83 81-02 | LOCK               |        | 1   |        |
| 9   | 537 00 87-01 | BRAKE LEVER        |        | 1   |        |
| 10  | 503 77 52-01 | BUSHING            |        | 1   |        |
| 11  | 503 70 99-01 | BRAKE SPRING       |        | 1   |        |
| 12  | 503 79 27-02 | SUPPORT            |        | 1   |        |
| 13  | 503 75 22-02 | BRAKE BAND ASSY    |        | 1   |        |
| 14  | 537 03 35-01 | CLUTCH COVER ASSY  |        | 1   |        |
| 15  | 537 03 35-71 | CLUTCH COVER ASSY  |        | 1   | 14     |
| 16  | 537 03 38-03 | LABEL              |        | 1   | 14, 15 |
| 17  | 503 76 29-02 | CHIP GUARD         |        | 1   | 14, 15 |
| 18  | 503 89 70-01 | SLEEVE             |        | 1   | 14, 15 |
| 19  | 503 21 28-10 | SCREW CCRPANT      |        | 1   | 14, 15 |
| 20  | 503 21 28-10 | SCREW CCRPANT      |        | 2   | 14     |
| 21  | 537 04 41-02 | CHAIN TENSIONER    |        | 1   | 14     |
| 22  | 537 01 68-01 | COVER              |        | 1   | 14, 21 |
| 23  | 503 23 00-66 | WASHER             |        | 1   | 14, 21 |
| 24  | 537 07 95-02 | WORM SCREW         |        | 1   | 14, 21 |
| 25  | 503 99 83-01 | PAWL               |        | 1   | 14, 21 |
| 26  | 537 01 74-01 | BEARING SLEEVE     |        | 1   | 14, 21 |
| 27  | 537 07 94-02 | WORM WHEEL         |        | 1   | 14, 21 |
| 28  | 503 23 00-63 | WASHER             |        | 1   | 14, 21 |
| 29  | 740 48 07-02 | O-RING             |        | 1   | 14, 21 |
| 30  | 501 51 72-01 | CHAIN GUIDE        |        | 1   | 14     |
| 31  | 503 22 00-01 | HEXAGON NUT FLANGE |        | 2   |        |
| 32  | 503 21 28-10 | SCREW CCRPANT      |        | 1   |        |
| 33  | 503 71 97-01 | SPIKE OUTER        |        | 1   |        |

**B** 362  
CLUTCH & OIL PUMP

## CLUTCH &amp; OIL PUMP

362, 2013-12


| Ref | Part no.     | Description    | Remark    | Qty | Kit |
|-----|--------------|----------------|-----------|-----|-----|
| 1   | 503 52 13-03 | OIL PUMP ASSY  |           | 1   |     |
| 2   | 503 62 49-01 | SEALING PLUG   |           | 1   | 1   |
| 3   | 503 52 15-01 | PUMP PISTON    |           | 1   | 1   |
| 4   | 503 23 00-04 | WASHER         |           | 2   | 1   |
| 5   | 501 61 58-01 | SPRING         |           | 1   | 1   |
| 6   | 503 81 30-01 | SPRING         |           | 1   | 1   |
| 7   | 503 81 13-01 | PIN SCREW      |           | 1   | 1   |
| 8   | 725 53 29-56 | SCREW IHSCM    |           | 2   |     |
| 9   | 537 20 78-07 | PUMP PINION    |           | 1   |     |
| 10  | 503 77 43-01 | OIL PIPE       |           | 1   |     |
| 11  | 503 64 47-01 | INLET OIL PIPE |           | 1   |     |
| 12  | 504 30 00-26 | SEALING        |           | 1   |     |
| 13  | 503 42 67-01 | OIL HOSE       |           | 1   |     |
| 14  | 501 54 41-02 | OIL SCREEN     |           | 1   |     |
| 15  | 503 27 21-01 | E-CLIP         |           | 1   |     |
| 16  | 503 75 24-01 | WASHER         |           | 1   |     |
| 17  | 503 93 24-71 | CLUTCH DRUM    | "3/8"x7T" | 1   |     |
| 17  | 503 93 24-72 | CLUTCH DRUM    | "3/8"x8T" | 1   |     |
| 18  | 501 59 80-02 | RIM            | "3/8"x7T" | 1   | 17  |
| 18  | 505 30 36-61 | RIM            | "3/8"x8T" | 1   | 17  |
| 19  | 503 43 20-01 | NEEDLE HOLDER  |           | 1   | 17  |
| 20  | 503 74 44-01 | CLUTCH ASSY    |           | 1   |     |
| 21  | 537 36 06-01 | CLUTCH SPRING  |           | 3   |     |
| 22  | 503 86 17-03 | CLUTCH DRUM    | "3/8"x7T" | 1   |     |
| 23  | 503 43 20-01 | NEEDLE HOLDER  |           | 1   |     |
| 24  | 503 23 00-59 | WASHER         |           | 1   |     |

**H** 362  
CRANKCASE


39

Ⓐ 503 64 72-01  
Set of gaskets

| Ref | Part no.     | Description          | Remark             | Qty | Kit |
|-----|--------------|----------------------|--------------------|-----|-----|
| 1   | 503 62 68-08 | CRANKCASE ASSY       |                    | 1   |     |
| 2   | 503 96 70-01 | BUSHING              |                    | 1   | 1   |
| 3   | 503 26 03-01 | SEALING RING         |                    | 1   | 1   |
| 4   | 503 75 18-01 | PIN KNEE-JOINT       |                    | 1   | 1   |
| 5   | 501 27 08-01 | GUIDE BUSHING        |                    | 1   | 1   |
| 6   | 501 27 08-01 | GUIDE BUSHING        |                    | 1   | 1   |
| 7   | 537 05 13-01 | BAR BOLT             |                    | 2   | 1   |
| 8   | 503 21 28-10 | SCREW CCRPANT        |                    | 1   |     |
| 9   | 537 04 66-01 | KIT                  |                    | 1   |     |
| 10  | 503 74 93-01 | SCREW                |                    | 1   |     |
| 11  | 503 20 02-12 | SCREW IHSCFM         |                    | 4   |     |
| 12  | 503 62 73-03 | CARBURETTOR AREA BAS |                    | 1   |     |
| 13  | 503 73 44-01 | GROMMET              |                    | 1   |     |
| 14  | 503 62 77-01 | CHOKE CONTROL        |                    | 1   |     |
| 15  | 579 46 89-01 | SUPPORT              |                    | 1   |     |
| 16  | 537 09 54-01 | GROMMET              |                    | 1   |     |
| 17  | 725 53 31-65 | SCREW IHSCM          |                    | 2   |     |
| 18  | 501 68 68-01 | CHAIN CATCHER        |                    | 1   |     |
| 19  | 503 62 72-01 | GASKET CRANKCASE     |                    | 1   | 39  |
| 20  | 503 85 73-01 | COVER                |                    | 1   |     |
| 21  | 505 27 57-19 | SEALING RING         |                    | 1   |     |
| 22  | 503 62 84-01 | AIR NOZZLE           |                    | 1   |     |
| 23  | 503 20 02-12 | SCREW IHSCFM         |                    | 1   |     |
| 24  | 503 84 61-01 | BUFFER               |                    | 1   |     |
| 25  | 537 21 52-02 | TANK CAP ASSY        |                    | 1   |     |
| 26  | 503 57 89-01 | HOLDER               |                    | 1   | 25  |
| 27  | 537 21 50-01 | SEALING              |                    | 1   | 25  |
| 28  | 503 20 08-70 | SCREW IHSCM          |                    | 6   |     |
| 29  | 537 40 35-01 | FILTER               |                    | 1   |     |
| 30  | 530 02 61-19 | CHECK VALVE          |                    | 1   |     |
| 31  | 537 04 29-01 | BUMPER               |                    | 1   |     |
| 32  | 503 20 07-80 | SCREW IHSCFM         |                    | 1   |     |
| 33  | 537 02 44-01 | WEAR PROTECTION      |                    | 1   |     |
| 34  | 537 08 92-01 | CHAIN CATCHER        |                    | 1   |     |
| 35  | 503 20 02-16 | SCREW IHSCFM         |                    | 2   |     |
| 36  | 537 01 71-01 | BARKSTØD             |                    | 1   |     |
| 37  | 503 22 24-01 | LOCKING NUT          |                    | 1   |     |
| 38  | 503 64 79-02 | BARKSTØD             |                    | 1   |     |
| 39  | 503 64 72-01 | GASKET KIT           | A = Set of gaskets | 1   |     |

**E** 362  
CRANKSHAFT


| Ref | Part no.     | Description     | Remark | Qty | Kit |
|-----|--------------|-----------------|--------|-----|-----|
| 1   | 503 74 87-03 | CRANKSHAFT ASSY |        | 1   |     |
| 2   | 503 74 44-01 | CLUTCH ASSY     |        | 1   | 1   |
| 3   | 503 77 91-01 | SLEEVE          |        | 1   | 1   |
| 4   | 503 26 30-19 | O-RING          |        | 1   | 1   |
| 5   | 503 25 08-01 | BEARING         |        | 2   |     |
| 6   | 577 57 24-01 | NEEDLE BEARING  |        | 1   |     |

**C** 362  
CYLINDER COVER

## CYLINDER COVER

362, 2013-12

| Ref | Part no.     | Description         | Remark | Qty | Kit |
|-----|--------------|---------------------|--------|-----|-----|
| 1   | 503 62 78-07 | CYLINDER COVER ASSY | Std    | 1   |     |
| 2   | 503 98 74-01 | LABEL               |        | 1   | 1   |
| 3   | 503 20 34-74 | SCREW CRPANMO       |        | 3   | 1   |
| 4   | 503 62 80-01 | FILTER COVER        | Std    | 1   | 1   |
| 5   | 503 74 01-02 | SNAP                |        | 2   | 1   |
| 6   | 537 01 65-01 | SUPPORT             |        | 1   |     |

**D** 362  
CYLINDER PISTON 


13

**A** 503 64 72-01  
**Set of gaskets**

## CYLINDER PISTON

362, 2013-12

| Ref | Part no.     | Description         | Remark             | Qty | Kit  |
|-----|--------------|---------------------|--------------------|-----|------|
| 1   | 503 93 90-05 | CYLINDER ASSY       |                    | 1   |      |
| 2   | 503 69 13-03 | PISTON ASSY         |                    | 1   | 1    |
| 3   | 503 55 22-01 | PLUG                |                    | 1   | 1    |
| 4   | 577 57 24-01 | NEEDLE BEARING      |                    | 1   |      |
| 5   | 503 71 53-01 | DECOMPRESSION VALVE |                    | 1   |      |
| 6   | 725 53 33-55 | SCREW IHSCM         |                    | 4   |      |
| 7   | 503 23 51-11 | SPARK PLUG          | BPMR7A             | 1   |      |
| 8   | 503 96 15-01 | GASKET              |                    | 1   | 13   |
| 9   | 503 28 90-15 | PISTON RING         |                    | 1   | 1, 2 |
| 10  | 737 43 12-00 | SNAP RING           |                    | 2   | 1, 2 |
| 11  | 503 77 59-01 | GASKET MUFFLER      |                    | 1   | 13   |
| 12  | 503 77 58-02 | HEAT DEFLECTOR      |                    | 1   |      |
| 13  | 503 64 72-01 | GASKET KIT          | A = Set of gaskets | 1   |      |


**J** 362  
FUEL TANK

## FUEL TANK

362, 2013-12


| Ref | Part no.     | Description           | Remark | Qty | Kit |
|-----|--------------|-----------------------|--------|-----|-----|
| 1   | 544 11 40-07 | FUEL TANK             |        | 1   |     |
| 2   | 581 75 61-06 | FUEL HOSE             |        | 1   | 1   |
| 3   | 537 09 93-01 | CONNECTION BEND       |        | 1   | 1   |
| 4   | 537 09 22-01 | TANK VENT ASSY        |        | 1   | 1   |
| 5   | 503 71 76-01 | THROTTLE WIRE ASSY    |        | 1   | 1   |
| 6   | 720 12 40-20 | PARALLEL PIN          |        | 1   | 1   |
| 7   | 503 55 66-01 | THROTTLE LOCKOUT      |        | 1   | 1   |
| 8   | 503 73 64-01 | SPRING                |        | 1   | 1   |
| 9   | 503 82 98-01 | THROTTLE TRIGGER      |        | 1   | 1   |
| 10  | 720 12 72-20 | PARALLEL PIN          |        | 1   | 1   |
| 11  | 503 89 56-01 | ANTIVIBRATION ELEMENT | Std    | 1   |     |
| 11  | 503 89 56-02 | ANTIVIBRATION ELEMENT | Hard   | 1   |     |
| 12  | 537 21 52-02 | TANK CAP ASSY         |        | 1   |     |
| 13  | 503 57 89-01 | HOLDER                |        | 1   | 12  |
| 14  | 537 21 50-01 | SEALING               |        | 1   | 12  |
| 15  | 581 75 62-02 | FUEL HOSE             |        | 1   |     |
| 16  | 503 44 32-01 | FILTER                |        | 1   |     |
| 17  | 503 63 76-01 | ANTIVIBRATION ELEMENT | Std    | 1   |     |
| 17  | 503 63 76-02 | ANTIVIBRATION ELEMENT | Hard   | 1   |     |

**K** 362  
HANDLE



| Ref | Part no.     | Description           | Remark | Qty | Kit |
|-----|--------------|-----------------------|--------|-----|-----|
| 1   | 503 62 67-71 | FRONT HANDLE ASSY     |        | 1   |     |
| 2   | 503 21 49-72 | SCREW IHSCFT          |        | 4   | 1   |
| 3   | 503 21 05-22 | SCREW IHSCFT          |        | 1   | 1   |
| 4   | 503 63 75-02 | ANTIVIBRATION ELEMENT | Std    | 1   | 1   |
| 4   | 503 63 75-03 | ANTIVIBRATION ELEMENT | Hard   | 1   |     |

# **L** 362 IGNITION SYSTEM




## IGNITION SYSTEM

362, 2013-12

| Ref | Part no.     | Description     | Remark | Qty | Kit |
|-----|--------------|-----------------|--------|-----|-----|
| 1   | 501 48 54-02 | SPARK PLUG CAP  |        | 1   |     |
| 2   | 544 04 71-01 | IGNITION MODULE |        | 1   |     |
| 3   | 503 20 02-20 | SCREW IHSCFM    |        | 2   |     |
| 4   | 503 71 82-01 | SWITCH          |        | 1   |     |
| 5   | 503 62 61-01 | CABLE           |        | 1   |     |
| 6   | 503 89 76-01 | CABLE           |        | 1   |     |
| 7   | 503 21 28-10 | SCREW CCRPANT   |        | 1   |     |
| 8   | 503 22 04-01 | NUT             |        | 1   |     |
| 9   | 537 05 16-05 | FLYWHEEL ASSY   |        | 1   |     |
| 10  | 501 67 35-01 | SPRING          |        | 2   | 9   |
| 11  | 503 23 00-42 | WASHER          |        | 2   | 9   |
| 12  | 537 01 55-01 | STARTER PAWL    |        | 2   | 9   |
| 13  | 501 81 99-01 | SCREW           |        | 2   | 9   |


**F** 362  
MUFFLER



## MUFFLER

362, 2013-12

| Ref | Part no.     | Description           | Remark | Qty | Kit |
|-----|--------------|-----------------------|--------|-----|-----|
| 1   | 544 02 97-02 | MUFFLER ASSY          | DF     | 1   |     |
| 2   | 724 12 87-59 | SCREW CRPANM          |        | 1   | 1   |
| 3   | 503 76 64-02 | SPARK ARRESTOR SCREEN |        | 1   | 1   |
| 4   | 725 53 70-55 | SCREW IHSCM           |        | 2   |     |
| 5   | 579 02 59-01 | SUPPORT               |        | 1   |     |
| 6   | 503 20 07-74 | SCREW IHSCFM          |        | 2   |     |
| 7   | 503 20 07-02 | SCREW IHSCFM          |        | 2   |     |
| 8   | 544 02 95-01 | MUFFLER ASSY          | Tube   | 1   |     |
| 8   | 544 02 95-02 | MUFFLER ASSY          | Jungle | 1   |     |

**M** 362  
STARTER

## STARTER

362, 2013-12

| Ref | Part no.     | Description          | Remark | Qty | Kit  |
|-----|--------------|----------------------|--------|-----|------|
| 1   | 503 62 81-71 | STARTER ASSY         |        | 1   |      |
| 2   | 503 21 52-16 | SCREW IHSCFT         |        | 1   | 1    |
| 3   | 503 85 96-01 | STARTER PULLEY       |        | 1   | 1    |
| 4   | 522 03 73-01 | STARTER HANDLE       |        | 1   | 1    |
| 5   | 503 43 29-02 | STARTER CORD         |        | 1   | 1    |
| 6   | 503 78 72-01 | RECOIL SPRING        |        | 1   | 1    |
| 7   | 503 62 82-01 | STARTER HOUSING      |        | 1   | 1    |
| 8   | 537 08 67-01 | BUSHING              |        | 1   | 1, 7 |
| 9   | 501 63 06-01 | REINFORCEMENT SLEEVE |        | 1   | 1, 7 |
| 10  | 544 08 03-01 | SCREW CIHPANMO       |        | 4   | 1, 7 |
| 11  | 537 23 02-15 | LABEL                |        | 1   |      |
| 12  | 503 62 83-01 | AIR CONDUCTOR        |        | 1   |      |