

MAC 5-10G

Serial Numbers Prefixed 1-

Figure and Item numbers are referenced to the Illustrated Parts List, P/N 65678 unless otherwise indicated on this parts list sheet. Numbers in black circles refer to notes at the bottom of the page. Numbers in parenthesis following the part number indicate a quantity change from the illustrated parts list.

FIG. & ITEM	PART NUMBER	NOMENCLATURE	FIG. & PART NUMBER	NOMENCLATURE	FIG. & PART NUMBER	NOMENCLATURE
1-	Fig. reference		1-47	66232	Insulator	
1-2	110403	Screw	1-48	102290	Screw	
1-3	110448 ①	Screw	1-49	63475 ⑥	Lockplate	
1-A	103174 ②	Lockwasher	1-50	63325	Washer	
1-B	100003 ③	Washer	1-51	110353	Screw	
1-C	64563 ④	Bracket	1-52	102388	Screw	
1-4	Fig. reference		1-53	100352	Washer	
1-5	102761	Screw	1-54	63070	Brace	
1-6	100352	Washer	1-55	Fig. reference		
1-7	61678	Plug	1-56	64852	Gasket	
1-8	101326	Nut	1-57	63258A	Insulator	
1-9	102130	Screw	1-58	65741	Gasket	
1-10	100153	Lockwasher	1-59	64846	Kit - Sp. Arr.	
1-11	63484	Clamp	1-60	101284	Screw	
1-12	66341	Frame	1-61	110264	Washer	
1-D	62271 ⑤	Plug	1-62	62380	Cover	
1-13	103746	Nut	1-63	62379B	Baffle	
1-14	Fig. reference		1-64	64601	Body	
1-15	103879	Key	1-65	110341	Screw	
1-16	66032	Drum & Gear	1-66	104534	Screw	
1-17	65748	Seal	1-67	104849	Screw	
1-18	102765	Screw	1-68	63748	Gasket	
1-19	100003	Washer	1-69	65676	Shroud	
1-20	Fig. reference		1-70	63993	Insulator	
1-21	106104	"O" Ring	1-71	Fig. reference		
1-22	65750	Cover				
1-23	65720	Nut	2-1	65471	Clutch	
1-24	64749	Nameplate	2-2	63999	Spring	
1-25	65740	Screen	2-3	64583	Cover	
1-26	61721D	Cap Assy	2-4	62198B	Shoe	
1-27	64762	Cover	2-5	65475	Rotor	
1-28	63040	Spring	2-6	65472	Rivet	
1-29	62316	Guide	2-7	62328	Spring	
1-30	63041	Valve	2-8	64857	Pawl	
1-31	65671	Gasket	2-9	65473	Washer	
1-32	110402	Screw	2-	65880	Starter	
1-33	63288	Cover	2-10	62191A	Insert	
1-34	63270	Spacer	2-11	62190A	Handle	
1-35	62102	Gasket	2-12	62371	Retainer	
1-36	64848	Hose	2-13	63985	Shield	
1-37	63932	Filter	2-14	63986	Washer	
1-38	62978	Screw	2-15	110470	Rivet	
1-39	63073	Housing	2-16	59952A	Rope	
1-40	103356	Screw	2-17	65526	Drum	
1-41	64856	Washer	2-18	36059	Spring	
1-42	63325	Washer	2-19	63987	Shield	
1-43	65726	Sleeve	2-20	61635A	Bushing	
1-44	Fig. reference		2-21	65879	Housing	
1-45	65758	Rod				
1-46	65739	Gasket				

Changes in Figure 1.

3-1	66649 ⑦	Tank Assy
3-A	105788	Rivet
3-2	64872	Grip
3-3	105673	Pin
3-4	66194	Button
3-5	64871	Button & Rod
3-6	61696	Seal
3-7	110378	Pin
3-8	65734	Spring
3-9	65864	Trigger
3-10	66156	Rod
3-11	105249	Screw
3-12	64621	Shield
3-13	64721	Bracket
3-14	64650	Spring
3-15	66306	Lever
3-16	110469	Screw
3-17	65873	Wire
3-18	65860	Button
4-	66511	Carburetor
4-1	101289	Ring
4-2	65859	Spring
4-3	65677	Retainer
4-4	65617	Plug
4-5	105617	"O" Ring
4-6	66552	Plunger
4-7	66551	"O" Ring
4-8	110483	Screw

Continued

NOTES

Notes 1, 2, 3, 4, 5 - See changes in Figure 1 on this page.

- ① Screw - Skt hd 10-24 x 3-1/4
- ② Lockwasher - #10
- ③ Washer - #10
- ④ Bracket - Frame
- ⑤ Plug - Frame

⑥ Lockplate replaces Washer, P/N 64856

⑦ Tank Assy includes two Rivets, P/N 105788, which must be removed for installation of compression release bracket screws. Item No. 2 to 9 inclusive, are not included in this tank assembly.

FIG. & ITEM	PART NUMBER	NOMENCLATURE	FIG. & ITEM	PART NUMBER	NOMENCLATURE	FIG. & ITEM	PART NUMBER	NOMENCLATURE
6-43	66560	12 Crankcase	6-57	63225	Needle Set	1	66285	Manual
6-44	62105	Screw	6-58	65746	Oil Seal	2	51445A	Wrench
6-45	62842	Washer	6-59	63464	Ring	3	63233	Piston Assy
6-46	110404	Screw	6-60	63429B	Bearing	4	63291	Ring Set
6-47	110288	Screw	6-61	66030	Insert Assy	5	103085	Bearing
6-48	63607	Screw	6-62	65747	Oil Seal	6	63234	Piston Assy
6-49	63606	Washer	6-63	63699	Ring	7	63292	Ring Set
6-50	100010	Cotter	6-64	104357	Bearing	8	103085	Bearing
6-51	65389	Pin	6-65	63401A	Crankshaft	9		14
6-52	63287	Piston	6-66	105221	Screw	10	65325	Screen
6-53	63290	Ring Set	6-67	101191	Nut	11	63432	Spark Plug
6-54	103085	Bearing	6-68	65363	Guard	12	65778	Spark Plug
6-55	65401	Conn Rod	6-69	64714	13 Valve	13	63490	Tool
6-56	61627A	Screw				14	65712	15 Timing Guide

ACCESSORY ITEMS

NOTES

- 12** Crankcase Assy includes Compression Release Valve, P/N 64714.
- 13** Valve included in Crankcase Assy, P/N 66560.

- 14** Wrap-around frame is standard equipment. See Figure 1, page 1 of this list.
- 15** Timing Guide added to Accessory list.



McCULLOCH CORPORATION
6101 WEST CENTURY BLVD., LOS ANGELES, CALIFORNIA 90045

McCULLOCH OF CANADA, LTD.
77 BELFIELD ROAD, REXDALE, ONTARIO, CANADA

McCULLOCH INTERNATIONAL, INC.
POSTBUS 10, MALINES, BELGIUM
G.P.O. BOX 879, HONG KONG, B.C.C.

McCULLOCH OF AUSTRALIA PTY., LTD.
P.O. BOX 165, SOUTH GRANVILLE, N.S.W., AUSTRALIA

McCULLOCH INTERNATIONAL (U.S.), INC.
P.O. BOX 45466 LOS ANGELES, CALIFORNIA, U.S.A.

66540